

Tools required

#4 Philips screwdriver, #6 Philips screwdriver, 3/16" drill and bit, wall anchors

Instructions

1. Using a #4 Philips screwdriver, remove the power cord side end cap.
2. Slide out the light assembly.
3. Place the unit on wall in desired location.
4. Using a pencil mark the location of the holes.
5. Drill a 3/16" hole if not located on stud.
6. Insert a #6 wall anchor. *(not supplied)*
7. Place the unit over the holes.
8. Install #6 -1" screws.
9. Slide in the lamp assembly and graphic acrylic. *(see graphic installation below)*
10. Reinstall the end cap.

Graphic Installation

1. Ensure graphic width is equal to or less than the extrusion length by measuring inside of end caps.
2. In the bottom of graphic acrylic drill 2 - 3/16" diameter holes centred 5/32" up from edge.
3. Insert the supplied 3/16" diameter rod (5/8" long) into your drilled holes and centre.
4. Slide unit into groove.
5. Secure end cap.

****This sign is intended to be installed in accordance with the requirements of Article 600 of the National Electrical Code and/or other application local codes. This includes proper grounding and bonding of signs.****

